

Fitting a TeleVue Dioptrix to an APM Super Zoom eyepiece

In addition to the Dioptrix appropriate for your eyesight and the Super Zoom, you will need the Baader M43 extension (#2954250).



Separate the Dioptrix to give the lens ring and the engraved (green) ring. Loosely fit the engraved Dioptrix ring over the male thread on the M43 extension:



Then place the Dioptrx lens over the engraved ring and screw it home. This will grip the threads on the extension and hold it in place whilst still allowing the engraved ring to turn, to adjust for your astigmatism.



The whole assembly can then be used to replace the original eyeguard and retaining ring on the eyepiece. Since the Zoom lens does not rotate when its focal length is adjusted, the Dioptrx setting remains the same at all focal lengths. Use the Tele Vue lens cap.

